SUPER WINGS Kiddie Rides MANUAL




20210628


MAIN SCREEN



GAME SETING


---Game Settings---
Parameter Settings
Operating accounts
Hardware test
FactorySet
Exit
Ver:2.0.16

1：PARAMETER SETING




SETING NAME	SPECIFIC PARAMETER
How many scores for one coin	1～5000
How many scores for one game	0（free）～100
Reward Scores	1～9999
Reward Numbers	0（no reward）～1000
Rewards Accumulate	Accumulate, Not Accumulate
Game Volume	0,1,2,3,4,5,6,7,8,9,10
Game Time	1～300
Time to Play Again	1～120
Demo Music	On,Off

2: Operating Account




Default Password: 888888




Seting Name	Introduction
Current Reset	Delete the current coin in or coin out
Password Change	Change the default password

3：Hardware Test



MAINBOARD WIRES CONNECTION



Seat Number	Site	Mark Number	Usage	Note
J6	1	5V	Power Plug	
	2	12V		
	3	24V		

Seat Number	Site	Mark Number	Usage	Note
J5	1	Speaker+	Speaker+	
	2	Speaker-	Speaker-	
	3	MJ+		
	4	GND	GND	
	5	MJ-		
	6	SW1	Up	
	7	SW2	Down	
	8	SW3		
	9	SW4		
	10	SW5	Confirm	
	11	MB1		
	12	GND	GND	
	13	MB2		
	14	12V		
	15	C+1	Coin in Signal 1	
	16	12V	12V	
	17	TBG1		
	18	12V		
	19	C+2		
	20	12V		
	21	TBG2		
	22	24V		
	23	TZ	SSR	
	24	C-	Sensor Signal	
	25	5V	5V	
	26	GND	GND	

Seat Number	Site	Mark Number	Usage	Note
J1	1	IN1	Right Direction	1P Control
	2	5v		
	3	IN2	Confirm	
	4	GND	GND	
	5	IN3	Left Direction	
	6	GND		
	7	IN4	Backtrack	
	8	GND		
	9	IN5		
	10	IN6		
	11	IN7		
	12	IN8		
	13	OUT1	FWD	
	14	12V		
	15	OUT2	REV	
	16	24/12		
	17	AD1		
	18	3V3		
	19	AD2		
	20	GND		